

4.27 m x 3.66 m (14 ft x 12 ft) MARQUEE PAVILION

Installation and Operating Instructions – YM12735

ITM. / ART. 1807257



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.
THIS ITEM IS INTENDED FOR OUTDOOR DOMESTIC USE ONLY. NOT FOR COMMERCIAL USE

Revised 10-01-2024

YARDISTRY®

Yardistry – North America
Toll Free Customer Support:

1.888.509.4382


Mon - Fri, 8:30 am - 5:00 pm EST
(excl. holidays)

English and French Spoken

For extended hours see our website:

www.yardistrystructures.com
info@yardistrystructures.com

Patents Pending



Height: 3.3 m / (10.8 ft)

Important Safety Notice!

Yardistry components are intended for privacy, decorative and ornamental use only.

Product is NOT INTENDED for the following:

- A safety barrier to prevent unsupervised access to pools, hot tubs, spas or ponds.
- As load bearing support for a building, structure, heavy objects or swings.
- Used in structures that trap wind, rain or snow that would create extra load on the product.

Accumulated snow must be removed from roof.

DO NOT climb or walk on roof for any reason.

Permanent structures may require a building permit. As the purchaser and or installer of this product you are advised to consult local planning, zoning and building inspection departments for guidance on applicable building codes and/or zoning requirements.

Wood is NOT flame retardant and will burn. Grills, fire pits and chimineas are a fire hazard if placed too close to a Yardistry structure. Consult user's manual of the grill, fire pit or chiminea for safe distances from combustible materials.

Wear gloves to avoid injury from possible sharp edges of individual elements before assembly.

During installation, follow all safety warnings provided with your tools and use OSHA approved safety glasses. Some structures may require two or more people to install safely.

Check for underground utilities before digging or driving stakes into the ground!

During assembly it is important to closely follow the instructions. Complete the assembly on a solid, level surface and follow the instructions to square up, level and anchor the structure. This will reduce the gaps at wood connections during assembly.

General Information

General Information: Wood components are manufactured with premium outdoor lumber (C. Lanceolata) which is protected with factory applied water-based stain. Knots, small checks (cracks) and weathering are naturally occurring and do not affect the strength of the product. Annual application of a water-based water repellent sealant or stain is important and will help reduce weathering and checks.

www.yardistrystructures.com

Questions?

Call toll free or write us at:

1 (888) 509-4382

support@yardistrystructures.com

Regular Hours: Mon - Fri, 8:30 am - 5:00 pm EST
(excl. holidays)

English and French Spoken

(For extended hours see our website)

www.yardistrystructures.com

Patents Pending

Limited Warranty

Yardistry warrants that this product is free from defect in materials and workmanship for a period of one (1) year from the original date of purchase. In addition, for any product with lumber, all lumber is warranted for five (5) years against rot and decay. This warranty applies to the original owner and registrant and is non-transferable.

Regular maintenance is required to assure the integrity of your product and is a requirement of the warranty. This warranty does not cover any inspection costs.

This Limited Warranty does not cover:

- Labor for replacement of any defective item(s);
- Incidental or consequential damages;
- Cosmetic defects which do not affect performance or integrity;
- Vandalism; improper use or installation; acts of nature, including but not limited to wind, storms, hail, floods, excessive water exposure;
- Minor twisting, warping, checking or any other natural occurring properties of wood that do not affect performance or integrity.

Yardistry products have been designed for safety and quality. Any modifications made to the original product could damage the structural integrity of the product leading to failure and possible injury. Yardistry cannot assume any responsibility for modified products. Furthermore, modification voids any and all warranties.

This product is warranted for RESIDENTIAL USE ONLY. Yardistry disclaims all other representations and warranties of any kind, express or implied.

This Warranty gives you specific legal rights. You may have other rights as well which vary from state to state or province to province. This warranty excludes all consequential damages, however, some states/provinces do not allow the limitation or exclusion of consequential damages, and therefore this limitation may not apply to you.

AUSTRALIA: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Instructions for Proper Maintenance

Your Yardistry structure is designed and constructed of quality materials. As with all outdoor products it will weather and wear. To maximize the enjoyment, safety and life of your structure it is important that you, the owner, properly maintain it.

HARDWARE:

- Check metal parts for rust. If found, sand and repaint using a non-lead paint complying with 16 CFR 1303.
- Inspect and tighten all hardware after completion of assembly; after first month of use; and then annually. Do not over-tighten as to cause crushing and splintering of wood.
- Check for sharp edges or protruding screw threads, add washers if required.

WOOD PARTS:

- Applying a water repellent or stain (water-based) on a yearly basis is important maintenance to maintain maximum life and performance of the product.
- Check all wood members for deterioration, structural damage and splintering. Sand down splinters and replace deteriorated wood members. As with all wood, some checking and small cracks in grain is normal
- Some gapping may occur at some wood connections.

Assembly Guides

Tools Required: (not included)

- | | | |
|------------------------------|--------------------|------------------------|
| • Tape Measure | • 8 ft Step Ladder | • 6 ft Step Ladder x 2 |
| • Carpenters Level | • Safety Glasses | • Square |
| • Standard or Cordless Drill | • Adult Helper | • Ratchet |
| • 7/16", 1/2" & 9/16" Wrench | • Safety Gloves | |
| • 7/16", 1/2" & 9/16" Socket | • Hard Hat | |

Symbols:

Throughout these instructions symbols are provided in the top, right-hand corner of the page.



- Use Help, where this is shown, 2, 3 or 4 people are required to safely complete this step. To avoid injury or damage to the assembly make sure to get some help.



- Use a measuring tape to assure proper location



- Pre-drill a pilot hole before fastening screw or lag to prevent splitting of wood.



- Check that assembly is square before tightening bolts



- Check that the assembly is level



- One or more ladders are required to safely complete this step.

If you dispose of your Yardistry structure: Please disassemble and dispose of your unit so that it does not create any unreasonable hazards at the time it is discarded. Be sure to follow your local waste ordinances.

Assembly Tips

Following are some helpful tips to make the assembly process smooth and efficient.

PRE-ASSEMBLIES:

(i.e. Post and Beam Assemblies, Roof Rafter Assembly, etc)

- Work on a raised, solid and flat surface such as a table or saw horse.
- Keep all connections flush where shown in the instructions.
- When assembling the beams keep parts flat, straight and snug when connecting.

METAL PARTS:

- Roofing material may have sharp edges, wear safety gloves.
- Remove all plastic covering, on both sides of the metal panels, directly before installing each piece.
- Place roofing material on a non-abrasive surface before and after assembly as it can bend, dent and scratch easily.
- The roofing screws can easily crush the roof panels and roof edges when using a power drill. We recommend hand tightening the roofing screws so they sit snug and tight to the roofing material.

Permanent Installation Examples

Note: It is critically important you start with square, solid and level footings, concrete pad or deck to attach your Pavilion.

We supply Post Mounts with this structure which gives you the flexibility to permanently install your structure to a pre-existing or new wood or concrete surface.


- The hardware to attach the Post Mount to the structure is included.
- The hardware to mount the structure permanently will need to be purchased separately at your local hardware store.

If you are mounting to concrete footers see below for the correct locations and placement. Please double check for possibility of any underground utilities such as gas, telephone, cable or sprinkler lines.

Following are some examples of how to mount the structure to wood or concrete surfaces.


Refer to your local building and city codes, ordinances, neighborhood covenants, or height restrictions regarding this type of structure for guidance on acceptable installation requirements.

Concrete Footer





Permanent Installation Examples cont.

Concrete Patio [min. 12 ft 7 in x 13 ft (3.83 m x 3.96 m)] with 6 in (15.24) cm clearance on all sides




Wood Deck [min. 12 ft 7 in x 13 ft (3.83 m x 3.96 m)] with 6 in (15.24) cm clearance on all sides




Part Identification (Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger.)

4pc. (545) Rafter Brace 489 mm (19-1/4") FSC




Y50229-545

5pc. (547) Tie Brace 454 mm (17-7/8") FSC



Y50229-547

4pc. (550) Fascia 2344.7 mm (92-5/16") FSC




Y50229-550

2pc. (2121) Ridge Short 1541.4 mm (60-11/16") FSC



Y50229-2121

4pc. (548) Gable End 430 mm (16-15/16") FSC



Y50229-548

2pc. (2122) Ridge Long 2065.3 mm (81-5/16") FSC



Y50229-2122

2pc. (549) Gable Inside 2336.8 mm (92") FSC



Y50229-549

5pc. (546) Tie 2333.6 mm (91-7/8") FSC



Y50229-546

10pc. (539) Rafter A 2272.1 mm (89-7/16") FSC



Y50229-539

4pc. (540) Rafter B 2272.1 mm (89-7/16") FSC



Y50229-540

4pc. (551) Left Gusset 1003.3 mm (39-1/2") FSC



Y50229-551

4pc. (577) Right Gusset 1003.3 mm (39-1/2") FSC




Y50229-577

8pc. (543) Strap Long 2326.9 mm (91-5/8") FSC




Y50229-543

4pc. (538) Side Beam Ends 729.8 mm (28-3/4") FSC




Y50229-538

8pc. (544) Strap Short 1279.1 mm (50-3/8") FSC




Y50229-544

2pc. (537) Side Beam Inside 2223.4 mm (87-1/2") FSC



Y50229-537

4pc. (536) Side Beam Outside 1803.4 mm (71") FSC



Y50229-536

4pc. (535) Gable Beam 1943.1 mm (76-1/2") FSC



Y50229-535

Part Identification (Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger.)

4pc. (2228) Post 2336.8 mm (92") FSC



200pc. Wood Screw #8 x 1-3/4" - (Y06091-513)




76pc. Wood Screw #8 x 2-1/2" - (Y06091-522)




30pc. Wood Screw #7 x 3/4" - (Y06091-003)




78pc. #8 x 1" Pan Screw - (Y06418-510)




100pc. #10 x 1-1/4" Pan Screw - (Y06418-711)




10pc. #10 x 2-1/2" Pan Screw - (Y06418-722)





10pc. Pan Screw #12 x 1-1/4" - (Y06418-611)




202pc. #8x 1" Hex Roofing Screw - (Y06736-510)



4pc. #8 x 3/4" Sheet Metal Screw - (Y06436-503)




36pc. 5/16" T-Nut (Y08518-300)




1pc. #2 x 2" (Y00400-005) Robertson Driver




1pc. Hex Driver (Y00400-004)



36pc. 5/16" Lock Washer (Y05318-300)



16pc. 3/8 x 1-1/4" Large Washer (Y05118-811)



172pc. 1/4-5/16 x 1-1/4" Large Washer (Y05118-311)



1pc. 1/8in (Y00400-002) Drill Bit



20pc. 1/4" Lock Nut (Y08318-203)




16pc. 5/16" Lock Nut (Y08318-303)




8pc. 3/8" Lock Nut (Y08318-803)

Hardware Identification (Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger.)


52pc. Lag Screw 5/16 x 3" (5/16 Head 1/4" Shank) - (Y06218-330)




4pc. Lag Screw 5/16 x 4-3/4" - (Y06218-343)




8pc. Lag Screw 5/16 x 1-3/4" - (Y06218-313)




10pc. Hex Bolt 1/4 x 2" - (Y07718-220)




6pc. Hex Bolt 1/4 x 2-3/4" - (Y07718-223)




4pc. Hex Bolt 1/4 x 4-3/4" - (Y07718-243)




12pc. Hex Bolt 5/16 x 1-1/2" - (Y07718-312)




16pc. Hex Bolt 5/16 x 2" - (Y07718-320)




8pc. Hex Bolt 5/16 x 2-1/4" - (Y07718-321)




8pc. Hex Bolt 5/16 x 3" - (Y07718-330)




8pc. Hex Bolt 5/16 x 3-3/4" - (Y07718-333)




4pc. Hex Bolt 3/8 x 8" (Y07718-880)



4pc. Hex Bolt 3/8 x 12-1/2" (Y07718-822)




Part Identification (Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger.)




Part Identification (Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger.)

1pc. Gazebo ID Plaque
(Y70800-104)




1pc. Weather Seal - Y70818-171
Ridge Clip (6PK)




1pc. Corner Bracket
(Y00418-160)




1pc. Rafter to Beam Bracket (10Pk)
(Y70818-175)




2pc. Tie Wrap Bracket Set (4Pk)
(Y70818-106)



1pc. Tie Wrap Bracket Set (2Pk)
(Y70818-163)



1pc. Tie Center Bracket Set (4Pk)
(Y70818-107)





1pc. Post Mount Set (8pk)
(Y70818-1036)




1pc. Jamb Mount Bracket Set (10Pk)
(Y70818-157)

2pc. FB Beam Insert (Y00418-1035)



1pc. Post to Beam Bracket Set (4pk)
(Y70818-1034)

Step 1: Inventory Parts - Read This Before Starting Assembly



- A.** This is the time for you to inventory all your hardware, wood and accessories, referencing the parts identification sheets. This will assist you with your assembly.
- Each step indicates which bolts and/or screws you will need for assembly, as well as any flat washers, lock washers, t-nuts or lock nuts.
- B.** If there are any missing or damaged pieces or you need assistance with assembly please contact the consumer relations department directly. Call us before going back to the store.

1-888-509-4382

Regular Hours: Mon - Fri, 8:30 am - 5:00 pm EST (excl. holidays)
English and French Spoken

support@yardistrystructures.com

- C.** Read the assembly manual completely, paying special attention to ANSI warnings; notes; and safety/maintenance information on pages 1 - 4.
- Follow the instructions in order.
 - This structure is designed to be assembled and installed ideally by four people, DO NOT attempt to install alone.
 - Consider the slope of elevation where you plan to install the structure. Also, check for gas, telephone, other utilities or sprinkler line locations prior to excavating any holes.
- D.** Before you discard your cartons fill out the form below.
- The carton I.D. stamp is located on the end of each carton.
 - Please retain this information for future reference. You will need this information if you contact the Consumer Relations Department.

PRODUCT NUMBER: YM12735

CARTON I.D. STAMP: __ __ __ __ __ 14459 __ (Box 1)

CARTON I.D. STAMP: __ __ __ __ __ 14459 __ (Box 2)


CARTON I.D. STAMP: __ __ __ __ __ 14459 __ (Box 3)

Step 2: Post Assemblies

A: At the bottom of one (2228) Post, place two Post Mounts flush to the bottom as shown in F2.1, F2.2 and F2.3. Attach with two 5/16 x 2" Hex Bolt (with two 1/4-5/16" large washers and one 5/16" lock nut) per mount.

B: Attach Post Mounts to the short sides of (2228) Post with one 5/16 x 1-3/4" Hex Lag Screw per Post Mount. (F2.4)

C: Repeat Steps A - B three more times to make four Post Assemblies.



Wood Parts

4 x (2228) Post

Component

8 x Post Mount

Hardware

16 x 5/16 x 2" Hex Bolt
(1/4-5/16" large washer x 2, 5/16" Lock Nut)


8 x 5/16 x 1-3/4" Hex Lag Screw
(1/4-5/16" large washer)

Step 3: Gable Beam Assembly


Part 1

A: Connect one (535) Gable Beam to a second (535) Gable Beam with one FB Beam Insert using two 5/16 x 1-1/2" Hex Bolts (with 5/16" lock washer, 1/4-5/16" large washer and 5/16" t-nut) as shown in F3.1 and F3.2.

F3.1



F3.2



Wood Parts

4 x (535) Gable Beam

Component

2 x FB Beam Insert

Hardware

4 x 5/16 x 1-1/2" Hex Bolt
(5/16" lock washer, 1/4-5/16" large washer, 5/16" t-nut)

Step 3: Gable Beam Assembly






Part 2

B: On the side without the FB Insert, place one (548) Gable End 2 in (5.08 cm) up from the bottom and 12-1/16 in (30.64 cm) from the end of (535) Gable Beam. Attach using three #8 x 2-1/2" Wood Screws. (F3.3, F3.4 and F3.5)

C: Attach (549) Gable Inside tight to (548) Gable End and 2 in (5.08 cm) up from the bottom of (535) Gable Beam using eight #8 x 2-1/2" Wood Screws. (F3.3, F3.4 and F3.5)

D: Attach (548) Gable End tight to (549) Gable Inside and 2 in (5.08 cm) up from the bottom of (535) Gable Beam using three #8 x 2-1/2" Wood Screws. (F3.3, F3.4 and F3.5)



Wood Parts

4 x (548) Gable End
2 x (549) Gable Inside

Hardware

28 x #8 x 2-1/2" Wood Screw

Step 3: Gable Beam Assembly


Part 3




E: Pre-drill using 1/8" drill bit and install two 5/16 x 3" Hex Lag Screws (with 1/4-5/16" large washer) into FB Beam Insert.

F: Repeats Steps A-E for one more time to make two Gable Beam Assemblies.

F3.6



F3.7



Hardware


4 x 5/16 x 3" Hex Lag Screw (1/4-5/16" large washer)

Step 4: Side Beam Assembly Part 1

A: Connect one (536) Side Beam Outside to a second (536) Side Beam Outside using two 5/16 x 1-1/2" Hex Bolts (with 5/16" lock washer, 1/4-5/16" large washer and 5/16" t-nut) as shown in F4.1.

B: Connect one (538) Side Beam End to each end of one (537) Side Beam Inside using one 5/16 x 1-1/2" Hex Bolts (with 5/16" lock washer, 1/4-5/16" large washer and 5/16" t-nut) in the top holes per end as shown in F4.1 and F4.2.

C: Repeat Steps A and B one more time to make two Side Beam Outside Assemblies and two Side Beam Inside Assemblies.



Wood Parts

- 4 x (536) Side Beam Outside
- 2 x (537) Side Beam Inside
- 4 x (538) Side Beam Ends

Hardware


- 8 x 5/16 x 1-1/2" Hex Bolt
(5/16" lock washer, 1/4-5/16" large washer, 5/16" t-nut)

Step 4: Side Beam Assembly Part 2

D: Place one Beam Insert in between one Side Beam Outside Assembly and one Side Beam Inside Assembly then fit tight together so the beam assembly ends are flush. Match the bolt holes and wood screw pilot holes in both beam assemblies and Beam Insert. (F4.3, F4.4 and F4.5)

E: Attach beam assemblies and Beam Insert together with four 5/16 x 3" Hex Bolts (with 5/16" lock washer, 1/4-5/16" large washer and 5/16" t-nut) and ten #8 x 2-1/2" Wood Screws. (F4.5 and F4.6)

F: Repeat Step D-E to make a second Side Beam Assembly.



Components


2 x Beam Insert

Hardware

20 x #8 x 2-1/2" Wood Screw

8 x 5/16 x 3" Hex Bolt
(5/16" lock washer, 1/4-5/16" large washer, 5/16" t-nut)

Step 5: Frame Assembly and Anchoring Part 1




A: Move your Post Assemblies to the final location. Make sure the ground is flat and level before continuing assembly.


B: With one person at each Post stand two complete Post Assemblies. A third person places one Side Beam Assembly against the outside of two Posts, flush to the tops and outside corners. Notice bolt hole orientation on the Side Beam Assembly and the short side of the Post Assembly is along the Side Beam Assembly. A fourth person attaches Beam to Post with one 3/8 x 12-1/2" Hex Bolt (with two 3/8" large washers and one 3/8" lock nut) per Post. The distance from the outside of one Post to the outside of the second Post should be 11 ft 7 in (3.53 m). (F5.1, F5.2 and F5.3)

C: Place one Gable Beam Assembly against the outside of two Posts, flush to the tops and outside corners and tight to Side Beam Assembly. Notice bolt hole orientation on the Gable Beam Assembly and the long side of the Post Assembly is along the Gable Beam Assembly. Attach Beam to Post with one 3/8 x 8" Hex Bolt (with two 3/8" large washers and one 3/8" lock nut) per Post. The distance from the outside of one Post to the outside of the second Post should be 12 ft (3.66 m). Continue until all four Beam Assemblies are attached and the corners are tight together. (F5.1 and F5.2) See F5.3 for accurate positioning of Posts.


F5.1



F5.2



F5.3



Hardware

- 4 x 3/8 x 8" Hex Bolt (3/8" large washer x 2, 3/8" lock nut)
- 4 x 3/8 x 12-1/2" Hex Bolt (3/8" large washer x 2, 3/8" lock nut)

Step 5: Frame Assembly and Anchoring Part 2




D: Make sure each corner is square and level then pre-drill using 1/8" drill bit and attach Side Beam Assembly to Post Assemblies with one 5/16 x 4-3/4" Lag Screw (with 1/4-5/16" large washer) per corner and Post to Beam bracket to Gable Beam Assembly and Post Assemblies with three 5/16 x 3" Lag Screws (with 1/4-5/16" large washer) and two #8 x 1" Pan Screws per corner as shown below. (F5.4 and F5.5)

E: Depending on what you are placing the Pavilion on will determine how you anchor it to that surface. Please refer to pages 6 and 7 for installation examples.

F5.4

Any hardware or extra materials for mounting will have to be purchased in advance.



Components

4 x Post to Beam Bracket

Hardware

4 x 5/16 x 4-3/4" Lag Screw (1/4-5/16" large washer)
 12 x 5/16 x 3" Lag Screw (1/4-5/16" large washer)
 8 x #8 x 1" Pan Screw

Step 6: Attach Gussets





Note: The bevelled ends on each gusset should always face away from the wood it is attaching to.

A: Make sure the assembly is still square and level then facing one Side Beam Assembly place one (577) Right Gusset on the right hand side so the top fits tight to the Side Beam Assembly and the bottom fits tight to the Post Assembly. Attach gusset to Side Beam Assembly with two 5/16 x 3-3/4" Hex Bolts (with 5/16" lock washer, 1/4-5/16" large washer and 5/16" t-nut). Pre-drill with a 1/8" drill bit then attach gusset to Post Assembly with two 5/16 x 3" Lag Screws (with 1/4-5/16" large washer). Repeat for the left hand side with one (551) Left Gusset. (F6.1 and F6.2)

B: Repeat Step A for Gable Beam Assembly using two 5/16 x 2-1/4" Hex Bolts (with 5/16" lock washer, 1/4-5/16" large washer and 5/16" t-nut) to attach gussets to Gable Beam Assembly. (F6.1 and F6.2)

C: Repeat Steps A and B so all 8 gussets are attached. (F6.1 and F6.2)




Wood Parts

- 4 x (577) Right Gusset
- 4 x (551) Left Gusset

Hardware

- 16 x 5/16 x 3" Lag Screw (1/4-5/16" large washer)
- 8 x 5/16 x 3-3/4" Hex Bolt (5/16" lock washer, 1/4-5/16" large washer, 5/16" t-nut)
- 8 x 5/16 x 2-1/4" Hex Bolt (5/16" lock washer, 1/4-5/16" large washer, 5/16" t-nut)

Step 7: Gable Frame Assembly




A: On the Gable Beam Assemblies measure to determine the middle of the beam and make a mark. (F7.1 and F7.2)

B: Place one Pavilion Truss Welded Assembly 1 in (2.54 cm) from the center mark and flush to the front of the Gable Beam Assembly. Pre-drill using 1/8" drill bit and attach using two 5/16 x 3" Hex Lag Screws (with 1/4-5/16" Large Washer). (F7.1, F7.2 and F7.3).


C: Place a second Pavilion Truss Welded Assembly 2 in (5.08 cm) from the first Pavilion Truss Welded Assembly, flush to the front of the Gable Beam Assembly. Pre-drill using 1/8" drill bit and attach using two 5/16 x 3" Hex Lag Screws (with 1/4-5/16" Large Washer). (F7.1, F7.2 and F7.3).

D: Repeat Steps A-C for the other Gable Beam Assembly.


F7.1



F7.2



F7.3



Components

4 x Pavilion Welded Truss Assembly

Hardware

8 x 5/16 x 3" Lag Screw (1/4-5/16" large washer)


Step 8: Frame Roof Panel Part 1



A: Lay out five (539) Rafter As and two (540) Rafter Bs on a hard flat surface as shown in F8.1. You will need lots of room for this step.

B: Place one (543) across the bottom of the (540) and four (539)'s, as shown in F8.1. Make sure (543) is flush to the outside edge of (540) and is centered on the fourth (539). Be sure the wider notch on (543) sits on (540). Follow by placing one (544) then another (543) and another (544) in the same manner. Make sure the assembly is square and pre-drill the bottom (543) with a 1/8" drill bit as shown in F8.1. Attach both (543) with ten S15 per board and both (544)'s with six S15 per board. The screws on the fourth (539) are inserted at an angle. (F8.1, F8.2, F8.3 and F8.4)

C: Place one (2121) Ridge Short on the angled ends of the rafters so the outside edges are flush then attach with six #8 x 2-1/2" Wood Screws. (F8.1 and F8.4)




Wood Parts

- 10 x (539) Rafter A
- 4 x (540) Rafter B
- 4 x (544) Strap Short
- 4 x (543) Strap Long
- 2 x (2121) Ridge Short

Hardware


- 64 x #8 x 1-3/4" Wood Screw
- 12 x #8 x 2-1/2" Wood Screw

Step 8: Frame Roof Panel Part 2



D: Tight to each (543) Strap Long place one (544) Strap Short and tight to the first two (544) Strap Shorts place one (543) Strap Long. Make sure the wider gap on each strap is on the outside. Make sure the assembly is square, pre-drill the bottom (544) Strap Short with a 1/8" drill bit, as shown below, then attach both (544) Strap Shorts with six #8 x 1-3/4" Wood Screws per board and both (543) Strap Longs with ten #8 x 1-3/4" Wood Screws per board. The screws where the straps meet are inserted at an angle. (F8.5 and 8.6)

E: Tight to (2121) Ridge Short attach one (2122) Ridge Long with eight #8 x 2-1/2" Wood Screws. (F8.5 and F8.7)



Wood Parts

- 4 x (544) Strap Short
- 4 x (543) Strap Long
- 2 x (2122) Ridge Long

Hardware

- 64 x #8 x 1-3/4" Wood Screw
- 16 x #8 x 2-1/2" Wood Screw



Step 8: Frame Roof Panel Part 3



F: Make sure frame is square. Measurements to be as shown in F8.9.

G: In the two middle gaps between (539) Rafter As place one (545) Rafter Brace flush to the top of (2121) Ridge Short and (2122) Ridge Long. Use two 1/4 x 4-3/4" Hex Bolts per brace as a guide to line up the bolt holes. Attach (545) Rafter Braces to (2122) Ridge Long and (2121) Ridge Short with eight #8 x 1-3/4" Wood Screws per brace. Remove each Hex Bolt as they will be used in a later step and not installed here. *Note: Angle is at the top of (545) Rafter Brace (F8.8 and F8.9)*

H: Repeat Steps A - G to create a second Roof Panel Frame.




Wood Parts

4 x (545) Rafter Brace

Hardware

32 x #8 x 1-3/4" Wood Screw



INSTALLING ROOFING MATERIAL


CAUTION!

Roofing material may have sharp edges! Wear gloves!


HANDLE WITH CARE!

Place roofing material on a non-abrasive surface before assembly as it can bend, dent and scratch easily.

**WARNING – DO NOT OVER TIGHTEN ROOFING SCREWS!
Over tightening screws will cause roofing material to crush.**



The roofing screws can easily crush the Roof Panels and Roof Edges when using a power drill. We recommend hand tightening the roofing screws so that they sit snug and tight to the roofing material.





INSTALLING ROOFING MATERIAL

CAUTION!

Roofing material may have sharp edges! Wear gloves!

BE SURE TO REMOVE ALL PLASTIC COVERING, ON BOTH SIDES OF THE ALUMINUM PANELS AND TRIM, DIRECTLY BEFORE INSTALLING EACH PIECE. *(One side is clear and the other is blue, both must be removed.)*



Step 9: Attach Roof Panels

Part 1




Note: Be sure to remove all plastic covering on both sides of the metal panels directly before installing each piece.

A: Make sure panel is still square then on one Roof Panel Frame place one Main Panel flush to the top and sides of the outside (540) Rafter B. Panels should be flush to the top of the (2122) Ridge Long and (2121) Ridge Short. There will be approximately a 5/16 in (7.9 mm) overhang at the bottom. There are no holes on the ribs at the top of the panels. (F9.1, F9.2, F9.3 and F9.4)

B: Place two more Main Panels beside the first then lastly one Right Side Panel so the panels overlap and screw holes line up as shown below. (F9.1 and F9.5)

C: Attach all four Panels to Roof Panel Frame using twelve #8 x 1" Hex Roofing Screws in locations shown in F9.1. Do not install screws to the outside (544) Strap Short and (543) Strap Long. Be sure not to overtighten screws.

D: Repeat Steps A - C for the second Roof Panel Frame.



Roof Panel Set:

- 6 x Main Panel
- 2 x Right Side Panel

Hardware


- 24 x #8 x 1" Hex Roofing Screw

Step 9: Attach Roof Panels Part 2




E: Place one Roof Edge Left and one Roof Edge Right on the bottom of each Roof Panel Frame so they meet tight and the ends are flush with the outside ends of (544) Short Strap and (543) Long Strap. Pre-drill the two end holes with a 1/8" drill bit then attach both Roof Edges with 18 #8 x 1" Hex Roofing Screws. (F9.6, F9.7 and F9.8)


F9.6



F9.8



F9.7



Components

- 2 x Roof Edge Left
- 2 x Roof Edge Right



Hardware

- 36 x #8 x 1" Hex Roofing Screw

Step 9: Attach Roof Panels

Part 3

F: Attach the three Main Panels and one Right Side Panel to one Roof Panel Frame using 63 #8 x 1" Hex Roofing Screws as shown in F9.9. On the outside (540) Rafter B's, in between the screw holes, four additional screws are to be inserted through the panels in the spaces indicated below (F9.10). Be sure not to overtighten screws.



Hardware

142 x #8 x 1" Hex Roofing Screw


Step 9: Attach Roof Panels Part 4



G: Place Weather Seal on the inside of two Ridge Clip Shorts then place one Ridge Clip Short flush to each side of Roof Panel Frame and 3-3/8 in (8.57 cm) up from the bottom of (2122) Ridge Long and (2121) Ridge Short, make sure not to compress Weather Seal. Attach with four #7 x 3/4" Wood Screws per Ridge Clip Short. Ridge Clip Shorts must cover the Roof Panels. (F9.11, F9.12, F9.13, F9.14 and F9.15)

H: Place Weather Seal on the inside of one Ridge Clip then place Ridge Clip in between both Ridge Clip Shorts. 3-3/8 in (8.57 cm) up from the bottom of (2122) Ridge Long and (2121) Ridge Short. Ridge Clip must cover the Roof Panels. Do not compress Weather Seal. Attach with seven #7 x 3/4" Wood Screws. (F9.11, F9.12, F9.13, F9.14 and F9.15)

I: Repeat Steps E - H for the second Roof Panel Frame.




Components

- 2 x Ridge Clip
- 4 x Ridge Clip Short
- 6 x Weather Seal

Hardware


- 30 x #7 x 3/4" Wood Screw

Step 10: Attach Roof Panels to Frame Part 1




A: With four assemblers lift one Roof Panel Frame up and over the Pavilion frame so it rests on the Pavilion Welded Truss Assemblies. The notches in the rafters sit tight on the Side Beam Assemblies. Lift the second Roof Panel Frame up and over the Pavilion frame so the two Roof Panel Frames are tight together and notches are tight to Side Beam Assemblies. **One assembler must remain on a ladder to hold Roof Panel Frame in place until secured.** (F10.1 and F10.2)

F10.2




F10.1




One assembler to support Roof Panel Frames at all times until secure

Step 10: Attach Roof Panels to Frame Part 2




B: From inside the assembly attach the two Roof Panel Frames together through each (545) Rafter Brace with four 1/4 x 4-3/4" Hex Bolts (with two 1/4-5/16" large washer and one 1/4" lock nut) and through (2122) Ridge Longs and (2121) Ridge Shorts with six 1/4 x 2-3/4" Hex Bolt (with two 1/4-5/16" large washer and one 1/4" lock nut). (F10.3, F10.4 and F10.5)

F10.3




Section of Roof Panel removed for Clarity

F10.5



F10.4





Hardware

4 x 1/4 x 4-3/4" Hex Bolt
(1/4-5/16" large washer x 2, 1/4" lock nut)


6 x 1/4 x 2-3/4" Hex Bolt
(1/4-5/16" large washer x 2, 1/4" lock nut)

Step 10: Attach Roof Panels to Frame Part 3




C: Loosely attach each of the (539) Rafter As to the inside of each Side Beam Assembly with one Rafter to Beam Bracket per rafter using one 1/4 x 2" Hex Bolt (with two 1/4-5/16" large washer and one 1/4" lock nut) per bracket. Push up on the center of the Roof Panels so the notches in the rafters are tight to the Side Beam Assembly then attach five #10 x 1-1/4" Pan Screws per bracket. Once screws are installed tighten bolts. (F10.6, F10.7 and F10.8)


F10.6



F10.7



F10.8



Component

Hardware

10 x Rafter to Beam Bracket

10 x 1/4 x 2" Hex Bolt
(1/4-5/16" large washer x 2, 1/4" lock nut)
50 x #10 x 1-1/4" Pan Screw


Step 10: Attach Roof Panels to Frame Part 4



D: Ensure Pavilion Truss Welded Assemblies are tight to (2121) Ridge Short and (2122) Ridge Long and flush to outside of (540) Rafter B's. Pre-drill using 1/8" Drill Bit and attach Pavilion Truss Welded Assemblies to (540) Rafter B's using three 5/16 x 3" Hex Lag Screws (with 1/4-5/16" Large Washer) per Truss. (F10.9)

E: Pre-drill using 1/8" Drill Bit and attach Pavilion Truss Welded Assemblies to (540) Rafter B's using three 5/16 x 3" Hex Lag Screws (with 1/4-5/16" Large Washer) per Truss. (F10.9)


F10.9



Hardware


12 x 5/16 x 3" Hex Lag Screw (1/4-5/16" large washer)

Step 11: Attach Ridge Caps Part 1



A: Slide Ridge Cap over the Ridge Clips towards the center of the roof. (F11.1 and F11.2)


B: With the swaged end facing in slide one Ridge Cap Short at each end of the roof over the Ridge Clips. Use the swaged end to help push the Ridge Cap to the center of the roof. Each Ridge Cap Short should be flush to the outside edge of the roof. (F11.1, F11.3 and F11.4)





Components:

- 1 x Ridge Cap
- 2 x Ridge Cap Short

Step 11: Attach Ridge Caps Part 2



C: Make sure the Ridge Cap Shorts are flush to the outside edge of the roof then attach each end of the Ridge Cap to each Ridge Cap Short with two #8 x 3/4" Metal Screws per side. (F11.5, F11.6 and F11.7)



Hardware

4 x #8 x 3/4" Sheet Metal Screw


Step 12: Attach Fascia




A: On one side of the assembly place two (550) Fascia against the outside rafters so the peaks meet in the center and they are tight together. Bottom of (550) Fascia to bottom of rafter should measure 1 in (25.4 mm) all along each (550) Fascia. Attach with ten #8 x 1-3/4" Wood Screws per (550) Fascia. (F12.1, F12.2 and F12.3)

B: Repeat for the other side of the assembly.


F12.1



F12.2
Inside View



F12.3



Wood Parts

4 x (550) Fascia

Hardware

40 x #8 x 1-3/4" Wood Screw


Step 13: Truss Assemblies

Part 1



A: Place one (547) Tie Brace centered, tight and square to the top of (546) Tie. Attach (546) Tie to (547) Tie Brace using two Jamb Mounts (one per side) with four #8 x 1" Pan Screws per mount. Repeat to complete five Tie Brace Assemblies. (F13.1 and F13.2)

B: Attach one Tie Wrap Bracket to each end of each (546) Tie with one #10 x 1-1/4" Pan Screw per bracket using the inside holes. (416) Tie is tight to end of bracket. (F13.1)



Wood Parts

5 x (546) Tie
5 x (547) Tie Brace

Components

10 x Tie Wrap Bracket
10 x Jamb Mount

Hardware

40 x #8 x 1" Pan Screw
10 x #10 x 1-1/4" Pan Screw

Step 13: Truss Assemblies


Part 2




C: Attach one Tie Center Bracket to the peak of five rafters, (2122) Ridge Long, (2121) Ridge Short with four #8 x 1" Pan Screws per bracket. Notice that three Tie Center Brackets face one way and one faces the opposite direction. It will only fit on this side. (F13.3 and F13.4)

F13.3

Notice Tie Center Bracket on opposite side for this location



F13.4



Components



4 x Tie Center Bracket

Hardware

16 x #8 x 1" Pan Screw

Step 13: Truss Assemblies


Part 3




D: With a helper place five (546) Tie with brackets tight against the rafters so (547) Tie Braces fit into Tie Center Brackets. Make sure (546) Ties are level then attach Tie Wrap Brackets to the rafters with two #10 x 1-1/4" Pan Screws on both sides of each bracket and one #12 x 1-1/4" Pan Screw on one side of each bracket. (F13.5, F13.6, F13.7 and F13.8)

E: Pre-drill with a 1/8" drill bit and secure Tie Wrap Brackets to (546) Tie and the rafter with one #10 x 2-1/2" Pan Screw on one side of each bracket. (F13.5, F13.6, F13.7 and F13.8)


F13.5




F13.8



F13.6
Front Side



F13.7
Back Side




Hardware

- 40 x #10 x 1-1/4" Pan Screw
- 10 x #12 x 1-1/4" Pan Screw
- 10 x #10 x 2-1/2" Pan Screw




Step 13: Truss Assemblies

Part 4



F: Secure four (547) Tie Braces to each Tie Center Bracket with two #8 x 1" Pan Screws per bracket. (F13.9 and F13.10)

G: Secure remaining (547) Tie Brace to (2122) Ridge Long and (2121) Ridge Short with one Corner Bracket using four #8 x 1" Pan Screws. (F13.9 and F13.11)



Components:



1 x Corner Bracket

Hardware

12 x #8 x 1" Pan Screw

Step 14: Attach Plaque

A: Attach Gazebo ID Plaque to a prominent location on your Pavilion with two #8 x 1" Pan Screws. This provides warnings concerning safety and important contact information. (F14.1 and F14.2)



Components

1 x Gazebo ID Plaque

Hardware

2 x #8 x 1" Pan Screw



Yardistry® 375 Sligo Road West, P.O. Box 10, Mount Forest, ON Canada N0G 2L1

Distributed by:
Costco Wholesale Corporation
P.O. Box 34535
Seattle, WA 98124-1535
USA
1-800-774-2678
www.costco.com

Costco Wholesale Canada Ltd.*
415 W. Hunt Club Road
Ottawa, Ontario
K2E 1C5, Canada
1-800-463-3783
www.costco.ca
* faisant affaire au Québec sous
le nom les Entrepôts Costco

Importado por:
Importadora Primex S.A. de C.V.
Blvd. Magnocentro No. 4
San Fernando La Herradura
Huixquilucan, Estado de México
C.P. 52765
RFC: IPR-930907-S70
(55)-5246-5500
www.costco.com.mx

Costco Wholesale Australia Pty Ltd
17-21 Parramatta Road
Lidcombe NSW 2141
Australia
www.costco.com.au

Costco Wholesale UK Ltd /
Costco Online UK Ltd
Hartspring Lane
Watford, Herts
WD25 8JS
United Kingdom
01923 213113
www.costco.co.uk

Costco Wholesale Spain S.L.U.
Polígono Empresarial Los Gavilanes
C/ Agustín de Betancourt, 17
28906 Getafe (Madrid) España
NIF: B86509460
900 111 155
www.costco.es

Costco Wholesale Iceland ehf.
Kauptún 3-7, 210 Gardabaer
Iceland
www.costco.is

Costco France
1 avenue de Bréhat
91140 Villebon-sur-Yvette
France
01 80 45 01 10
www.costco.fr

Costco Wholesale Japan Ltd.
2 Kakuchi, 2 Gaiku, Kaneda-Nishi
361 Urakura, Kisarazu shi
Chiba, 292-0007 Japan
0570-200-800
www.costco.co.jp

Costco Wholesale Korea, Ltd.
40, Iljik-ro
Gwangmyeong-si
Gyeonggi-do, 14347, Korea
1899-9900
www.costco.co.kr

Costco Wholesale New Zealand Limited
2 Gunton Drive
Westgate
Auckland 0814
New Zealand
www.costco.co.nz

Costco (China) Investment Co., Ltd.
Room 01 Mezzanine
No. 5178, Kang Xin Highway
Pudong New District
Shanghai
China 201315
+86-21-6257-7065

Costco Wholesale Sweden AB
Box 614
114 11 Stockholm
Sweden
www.costco.se

MADE IN CHINA / FABRIQUÉ EN CHINE / HECHO EN CHINA



Customer Registration Card - Carte d'inscription du client - Tarjeta de Registro del Cliente

First Name - Prénom - Primer Nombre	Initial - Initiale - Inicial	Last Name - Nom de famille - Apellido

Street - Rue - Calle	PO Box - Boîte postale - Casilla postal	Apt. No. - App.

City - Ville - Ciudad	State/Province - État/Province - Estado/Provincia

ZIP/Postal Code - ZIP/Code postal - Código Postal	Country - Pays - País

E-mail Address - Adresse courriel - Dirección de E-mail	Telephone Number - N° de téléphone - No. de Teléfono

Model Name - Nom du modèle - Nombre del Modelo	Model Number (from front cover) - N° du modèle (page de couverture) - Número de Modelo (de la portada)

Date of Purchase - Date d'achat - Fecha de Compra (mm/dd/yyyy) (mm/jj/aaaa) (mm/dd/aaaa)	Place of Purchase - Lieu d'achat - Comprado a

Comments - Commentaires - Comentarios :

Mail To - Envoyer par courrier à - Enviar por Correo a:

Yardistry
375 Sligo Road West, PO Box 10
Mount Forest, Ontario, Canada, N0G 2L0
Attention: Consumer Relations
À l'attention de : Service à la clientèle
Atención a: Servicio de Atención al Cliente

Online Registration - Enregistrement en ligne - Registro online:

www.yardistrystructures.com/warranty

1.888.509.4382

Hours/ Heures/ Horas: 8:30 am - 5:00 pm EST
(excl. holidays/ hors jours fériés/ excepto los días festivos)

English and French Spoken / Anglais et français parlés / Inglés y francés hablado

Yardistry would like to say "Thank you" for your time and feedback.

Yardistry aimerait vous remercier d'avoir pris le temps de répondre au sondage.

Yardistry quiere "Agradecerle" por su tiempo y su opinión.