

3.7 m x 2.8 m (12.1 ft x 9.3 ft) Contemporary Gazebo

Installation and Operating Instructions – YM12750



IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY
THIS ITEM IS INTENDED FOR OUTDOOR DOMESTIC USE ONLY.
NOT FOR COMMERCIAL USE.

HEIGHT:
2.7 m / 8.8 ft

Revised 12-18-2024

YARDISTRY®

Yardistry – North America
Toll Free Customer Support:

1.888.509.4382

Mon - Fri, 8:30 am - 5:00 pm EST
(excl. holidays)


English and French Spoken

For extended hours see our website:

www.yardistrystructures.com

info@yardistrystructures.com

Patents Pending



Important Safety Notice!

Yardistry components are intended for privacy, decorative and ornamental use only.

Product is NOT INTENDED for the following:

- A safety barrier to prevent unsupervised access to pools, hot tubs, spas or ponds.
- As load bearing support for a building, structure, heavy objects or swings.
- Used in structures that trap wind, rain or snow that would create extra load on the product.

Accumulated snow must be removed from roof.

DO NOT climb or walk on roof for any reason.

Permanent structures may require a building permit. As the purchaser and or installer of this product you are advised to consult local planning, zoning and building inspection departments for guidance on applicable building codes and/or zoning requirements.

Wood is NOT flame retardant and will burn. Grills, fire pits and chimineas are a fire hazard if placed too close to a Yardistry structure. Consult user's manual of the grill, fire pit or chiminea for safe distances from combustible materials.

Wear gloves to avoid injury from possible sharp edges of individual elements before assembly.

During installation, follow all safety warnings provided with your tools and use OSHA approved safety glasses. Some structures may require two or more people to install safely.

Check for underground utilities before digging or driving stakes into the ground!

During assembly it is important to closely follow the instructions. Complete the assembly on a solid, level surface and follow the instructions to square up, level and anchor the structure. This will reduce the gaps at wood connections during assembly.

General Information

General Information: Wood components are manufactured with premium outdoor lumber which is protected with factory applied water-based stain. Knots, small checks (cracks) and weathering are naturally occurring and do not affect the strength of the product. Annual application of a water-based water repellent sealant or stain is important and will help reduce weathering and checks.

www.yardistrystructures.com

Questions?

Call toll free or write us at:

1 (888) 509-4382

support@yardistrystructures.com

Regular Hours: Mon - Fri, 8:30 am - 5:00 pm EST
(excl. holidays)

English and French Spoken

(For extended hours see our website)

www.yardistrystructures.com

Patents Pending

Limited Warranty

Yardistry warrants that this product is free from defect in materials and workmanship for a period of one (1) year from the original date of purchase. In addition, for any product with lumber, all lumber is warranted for five (5) years against rot and decay. This warranty applies to the original owner and registrant and is non-transferable.

Regular maintenance is required to assure the integrity of your product and is a requirement of the warranty. This warranty does not cover any inspection costs.

This Limited Warranty does not cover:

- Labor for replacement of any defective item(s);
- Incidental or consequential damages;
- Cosmetic defects which do not affect performance or integrity;
- Vandalism; improper use or installation; acts of nature, including but not limited to wind, storms, hail, floods, excessive water exposure;
- Minor twisting, warping, checking or any other natural occurring properties of wood that do not affect performance or integrity.

Yardistry products have been designed for safety and quality. Any modifications made to the original product could damage the structural integrity of the product leading to failure and possible injury. Yardistry cannot assume any responsibility for modified products. Furthermore, modification voids any and all warranties.

This product is warranted for RESIDENTIAL USE ONLY. Yardistry disclaims all other representations and warranties of any kind, express or implied.

This Warranty gives you specific legal rights. You may have other rights as well which vary from state to state or province to province. This warranty excludes all consequential damages, however, some states/provinces do not allow the limitation or exclusion of consequential damages, and therefore this limitation may not apply to you.

AUSTRALIA: Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and for compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Instructions for Proper Maintenance

Your Yardistry structure is designed and constructed of quality materials. As with all outdoor products it will weather and wear. To maximize the enjoyment, safety and life of your structure it is important that you, the owner, properly maintain it.

HARDWARE:

- Check metal parts for rust. If found, sand and repaint using a non-lead paint complying with 16 CFR 1303.
- Inspect and tighten all hardware after completion of assembly; after first month of use; and then annually. Do not over-tighten as to cause crushing and splintering of wood.
- Check for sharp edges or protruding screw threads, add washers if required.

WOOD PARTS:

- Applying a water repellent or stain (water-based) on a yearly basis is important maintenance to maintain maximum life and performance of the product.
- Check all wood members for deterioration, structural damage and splintering. Sand down splinters and replace deteriorated wood members. As with all wood, some checking and small cracks in grain is normal
- Some gapping may occur at some wood connections.

Assembly Guides

Tools Required: (Not included)

- | | | |
|------------------------------|--------------------|------------------------------|
| • Tape Measure | • 8 ft Step Ladder | • 6 ft Step Ladder x 2 |
| • Carpenters Level | • Safety Glasses | • Square |
| • Standard or Cordless Drill | • Adult Helper | • Ratchet |
| • Claw Hammer | • Safety Gloves | • 7/16", 1/2" & 9/16" Socket |
| • 7/16" & 9/16" Wrench | • Hard Hat | |

Symbols:

Throughout these instructions symbols are provided in the top, right-hand corner of the page.




- Use Help, where this is shown, 2, 3 or 4 people are required to safely complete this step. To avoid injury or damage to the assembly make sure to get some help.



- Use a measuring tape to assure proper location



- Pre-drill a pilot hole before fastening screw or lag to prevent splitting of wood.



- Check the assembly is square before tightening bolts



- One or more ladders are required to safely complete this step.

If you dispose of your Yardistry structure: Please disassemble and dispose of your unit so that it does not create any unreasonable hazards at the time it is discarded. Be sure to follow your local waste ordinances.

Assembly Tips

Following are some helpful tips to make the assembly process smooth and efficient.

PRE-ASSEMBLIES:

(i.e. Post and Beam Assemblies, Roof Rafter Assembly, etc)

- Work on a raised, solid and flat surface such as a table or saw horse.
- Keep all connections flush where shown in the instructions.
- When assembling the beams keep parts flat, straight and snug when connecting.

METAL PARTS:

- Roofing material may have sharp edges, wear safety gloves.
- Remove all plastic covering, on both sides of the metal panels, directly before installing each piece.
- Place roofing material on a non-abrasive surface before and after assembly as it can bend, dent and scratch easily.
- The roofing screws can easily crush the roof panels and roof edges when using a power drill. We recommend hand tightening the roofing screws so they sit snug and tight to the roofing material.

Sealant Application Tips, Warning and First Aid Information

SEALANT:

- All surfaces to be clean, dry, dust and grease free before application with temperatures above 5°C (41°F), no warmer than 35°C (95°F).
- Remove cap and cut a small piece off the nozzle for a small bead.
- Apply sealant in small beads and smooth as required.
- To smooth sealant into the joint use a glove covered finger, putty knife, etc. Smooth sealant to create a continuous water-tight seal, diverting water into the gutter with an unimpeded flow into the gutter drain corner.
- Clean excess with a cloth or paper towel before it skins over.
- An initial bond will set in approximately 20 minutes and fully set in 24 hours.

WARNING:

- CAUSES SERIOUS EYE AND SKIN IRRITATION. Always wear safety glasses and rubber gloves when using product.
- KEEP OUT OF REACH OF CHILDREN.
- Prolonged or repeated exposure MAY CAUSE ORGAN DAMAGE. Provide ample ventilation.

FIRST AID:

- If ingested, DO NOT INDUCE VOMITING. Seek immediate medical attention.
- Eye contact: immediately flush eyes with water for at least 15 minutes. Remove contact lenses if present.
- Skin contact; wash thoroughly with soap and water. If eye/skin irritation persists or respiratory symptoms occur or develop, seek medical attention.

Use of this product can expose you to chemicals including Methanol, which is known to the State of California to cause birth defects and other reproductive harm. For more information, go to www.P65Warnings.ca.gov.

Dispose of contents and container in accordance with local regulations.

Permanent Installation Examples

Note: It is critically important you start with square, solid and level footings, concrete pad or deck to attach your Gazebo.

We supply Post Mounts with this structure which gives you the flexibility to permanently install your structure to a pre-existing or new wood or concrete surface.


- The hardware to attach the Post Mount to the structure is included.
- The hardware to mount the structure permanently will need to be purchased separately at your local hardware store.

If you are mounting to concrete footers see below for the correct locations and placement. Please double check for possibility of any underground utilities such as gas, telephone, cable or sprinkler lines.

Following are some examples of how to mount the structure to wood or concrete surfaces.


Refer to your local building and city codes, ordinances, neighborhood covenants, or height restrictions regarding this type of structure for guidance on acceptable installation requirements.

Concrete Footer





Permanent Installation Examples cont.

Concrete Patio [min. 2.70 m x 3.14 m (8' 10-5/16" x 10' 3-5/8")] with 15.24 cm (6") clearance on all sides



Wood Deck [min. 2.70 m x 3.14 m (8' 10-5/16" x 10' 3-5/8")] with 15.24 cm (6") clearance on all sides




Part Identification (

Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger.

)

10pc. (2346) - Strap - 1422.4 mm (56") - FSC



4pc. (2349) - Rafter A - Short - 1095.8 mm (43-1/8") - FSC



4pc. (2350) - Rafter A - Long - 2590.8 mm (102") - FSC




4pc. (2347) - Rafter B - Short - 1095.8 mm (43-1/8") - FSC



4pc. (2348) - Rafter B - Long - 2590.8 mm (102") - FSC




4pc. (2351) - Fascia - 1422.4 mm (56") - FSC




6pc. (2358) - Roof Eave Support - 320 mm (12-5/8") - FSC



2pc. (2357) - Back Post - 2353 mm (92-5/8") - FSC



2pc. (2356) - Front Post - 2590 mm (102") - FSC




Hardware Identification (Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger.)

1pc. - Roof Panel Set
(Y70836-1138)

4pc. - Panel B
(Y01036-579)

4pc. - Panel A
(Y01036-578)



4pc.
Post Mount (2pk)
(Y70818-1043)




1pc.
Roof Edge Center (2pk)
(Y70836-1139)




2pc.
Saddle Bracket (4pk)
(Y70841-992)


2pc.
Flat Roof Clip - Short
(Y01036-581)



1pc.
Gazebo ID Plaque
(Y70800-104)




1pc.
Front Truss Assembly
(Y70841-1135)




1pc.
Back Truss Weld Assembly
(Y70841-1136)

1pc.
Mid Truss Assembly
(Y70841-1134)




2pc.
Side Truss Weld Assembly
(Y70841-1137)



4pc.
Roof Back Edge
(Y01036-886)

1pc.
Flat Roof Cap - Short Top
(Y01036-1155)

1pc.
Flat Roof Cap - Bottom
(Y01036-582)



2pc.
Sealant Tube
(Y90100-001)

Hardware Identification (Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger.)


80pc. **(S2)** - Wood Screw #8 x 1-1/2"
(Y06091-512)




8pc. **(S11)** - Wood Screw #8 x 2" - (Y06091-520)




32pc. **(S3)** - Wood Screw #8 x 2-1/2" - (Y06091-522)




12pc. **(S4)** - Wood Screw #8 x 3" - (Y06091-530)



18 x **(S12)** - Pan Screw #10 x 1-1/4" - (Y06418-711)




4pc. **(SM0)** - Sheet Metal Screw #8 x 3/4"
(Y06436-503)



200pc. **(R0)** - Hex Roofing Screw #8x 1"
(Y06736-510)




1pc. Hex Driver - (Y00400-004)




1pc. #2 x 2" Robertson Driver - (Y00400-005)




1pc. 1/8" Drill Bit - (Y00400-002)




24pc. **(FW2)** - 5/16" Flat Washer
(Y05118-301)




76pc. **(FW12)** - 1/4-5/16 x 1-1/4" Large Washer
(Y05118-311)




42pc. **(LN2)** - 5/16" Lock Nut
(Y08318-303)



16pc. **(LW2)** - 5/16" Lock Washer
(Y05318-300)




16pc. **(TN2)** - 5/16" T-Nut
(Y08518-300)




Hardware Identification (Dimensions are approximate and are shown to assist in the identification of parts for assembly. Actual dimensions may be smaller or larger.)


16pc. **G3** - Hex Bolt 5/16 x 1-1/4" - (Y07718-311)




2pc. **G34** - Hex Bolt 5/16 x 2-3/4" - (Y07718-323)




16pc. **G37** - Hex Bolt 5/16 x 1-3/4" - (Y07718-313)




4pc. **G10** - Hex Bolt 5/16 x 3" - (Y07718-330)






4pc. **G7** - Hex Bolt 5/16 x 6-3/4" - (Y07718-363)



16pc. **G45** - Hex Bolt 5/16 x 7" - (Y07718-370)



Step 1: Inventory Parts - Read This Before Starting Assembly



- A.** This is the time for you to inventory all your hardware, wood and accessories, referencing the parts identification sheets. This will assist you with your assembly.
- Each step indicates which bolts and/or screws you will need for assembly, as well as any flat washers, lock washers, t-nuts or lock nuts.
- B.** If there are any missing or damaged pieces or you need assistance with assembly please contact the consumer relations department directly. Call us before going back to the store.

1-888-509-4382

Regular Hours: Mon - Fri, 8:30 am - 5:00 pm EST (excl. holidays)
English and French Spoken

support@yardistrystructures.com

- C.** Read the assembly manual completely, paying special attention to ANSI warnings; notes; and safety/maintenance information on pages 1 - 4.
- Follow the instructions in order.
 - This structure is designed to be assembled and installed ideally by four people, DO NOT attempt to install alone.
 - Consider the slope of elevation where you plan to install the structure. Also, check for gas, telephone, other utilities or sprinkler line locations prior to excavating any holes.
- D.** Before you discard your cartons fill out the form below.
- The carton I.D. stamp is located on the end of each carton.
 - Please retain this information for future reference. You will need this information if you contact the Consumer Relations Department.

PRODUCT NUMBER: YM12750



CARTON I.D. STAMP: __ __ __ __ __ 14459 __ (Box 1)

CARTON I.D. STAMP: __ __ __ __ __ 14459 __ (Box 2)


CARTON I.D. STAMP: __ __ __ __ __ 14459 __ (Box 3)

2 Post Assemblies

Complete this step twice



Bottom View



Wood Parts

2 x 2356

2 x 2357

Hardware



8 x G37 (FW12 x 2, LN2)

Components


2 x Post Mount (2pk)

3

Complete this step twice



Bottom View



Hardware

8 x G37 (FW12 x 2, LN2)


Components

2 x Post Mount (2pk)

4 Frame Assembly



Install truss centered
and straight on post



Hardware



4 x G45 (FW2, FW12, LN2)

Components

1 x Front Truss Assembly

5

Install truss centered
and straight on post



Hardware

4 x  (FW2, FW12, LN2)

Components

1 x Back Truss Weld Assembly


6

Move your Post Assemblies to the final location.

Make sure the ground is flat and level before continuing assembly.

With adult helpers stand up the Front Frame Assembly and Back Frame Assembly then place Side Truss Assembly on the side.

Install truss centered and straight on post.



Hardware



4 x (FW2, FW12, LN2)

Components

1 x Side Truss Weld Assembly

7

With adult helpers place Side Truss Assembly on the side.
Install truss centered and straight on post.





Hardware

4 x (FW2, FW12, LN2)

Components

1 x Side Truss Weld Assembly


**Hardware**4 x  (FW2 x 2, LN2)**Components**

1 x Middle Truss Assembly

9 Check Frame Dimensions




The diagonal distance between the inside of two posts should be 11 ft 1/16 in (3.35 m) (measuring from posts not Post Mounts)



10 Roof Panel Assembly

Complete this step twice
Note T-Nut orientation



Wood Parts


4 x 2349
4 x 2350

Hardware

8 x G3 (LW2, FW12, TN2)

11

Complete this step twice
Note T-Nut orientation



Wood Parts

4 x 2351


Hardware

16 x S3

12

Complete this step four times

Note T-Nut orientation



Wood Parts

4 x 2347

4 x 2348


Hardware

8 x G3 (LW2, FW12, TN2)

13

Complete this step twice

Note T-Nut orientation



Hardware





8 x S3

14

Complete this step twice

Make sure the Rafter Assembly is square

The diagonal distance between the corners of the Fascia's is 155-1/8 in [3.94 m]



Wood Parts

10 x 2346



Hardware

80 x S2


15

Flip Roof Panel over and install three (2358) on the back

Complete this step twice



Top View





Wood Parts

6 x 2358

Hardware

12 x S4



INSTALLING ROOFING MATERIAL


CAUTION!

Roofing material may have sharp edges! Wear gloves!




HANDLE WITH CARE!

Place roofing material on a non-abrasive surface before assembly as it can bend, dent and scratch easily.

WARNING – DO NOT OVER TIGHTEN ROOFING SCREWS!
Over tightening screws will cause roofing material to crush.



The roofing screws can easily crush the Roof Panels and Roof Edges when using a power drill. We recommend hand tightening the roofing screws so that they sit snug and tight to the roofing material.







INSTALLING ROOFING MATERIAL

CAUTION!


Roofing material may have sharp edges! Wear gloves!

BE SURE TO REMOVE ALL PLASTIC COVERING, ON BOTH SIDES OF THE ALUMINUM PANELS AND TRIM, DIRECTLY BEFORE INSTALLING EACH PIECE. *(One side is clear and the other is blue, both must be removed.)*





INSTALLING ROOFING MATERIAL



16 Roof Assembly



Note hole orientation on the Roof Panels.

Place Roof Panels on top of Roof Panel Assembly.


Refer to page 30 for Roof Panel Identification.

On the left side of Flat Roof Panel B between the first two ribs apply a small, evenly distributed bead of sealant over the perimeter of the flat surface.

Note: All surfaces to be clean, dry, dust and grease free before application with temperatures above 5°C (41°F), no warmer than 35°C (95°F).

- Apply sealant in small beads and smooth as required.
- Clean excess with a cloth or paper towel before it skins over.
- Always wear safety glasses and rubber gloves when using product.

See page 6 for Warning and First Aid Information.



Components

2 x Roof Panel B
1 x Sealant Tube

17

Refer to page 30 for Roof Panel Identification.



Across the top of Roof Panel A and Roof Panel B apply two small, evenly distributed beads of sealant 1-1/2 in apart.



Note: All surfaces to be clean, dry, dust and grease free before application with temperatures above 5°C (41°F), no warmer than 35°C (95°F).

- Apply sealant in small beads and smooth as required.
- Clean excess with a cloth or paper towel before it skins over.
- Always wear safety glasses and rubber gloves when using product.

See page 6 for Warning and First Aid Information.



Components

2 x Roof Panel A
1 x Sealant Tube

18


Refer to page 30 for Roof Panel Identification.

On the left side of Flat Roof Panel B between the first two ribs apply a small, evenly distributed bead of sealant over the perimeter of the flat surface.

Note: All surfaces to be clean, dry, dust and grease free before application with temperatures above 5°C (41°F), no warmer than 35°C (95°F).


- Apply sealant in small beads and smooth as required.
- Clean excess with a cloth or paper towel before it skins over.
- Always wear safety glasses and rubber gloves when using product.

See page 6 for Warning and First Aid Information.




Components

2 x Roof Panel B




**Components**

2 x Roof Panel A



21

Apply sealant to the inside groove of two Flat Roof Clip - Shorts and two Flat Roof Clip Longs



Hardware


22 x R0

Components

2 x Flat Roof Clip - Long
2 x Flat Roof Clip - Short

22

DO NOT overtighten screws, could cause damage to roofing material



Hardware


5 x (R0)

Components

2 x Side Fascia

23

DO NOT overtighten screws, could cause damage to roofing material






Hardware

5 x (R0)

Components

2 x Side Fascia




Hardware

2 x G7 (FW12 x 2, LN2)

25

Do not tighten until Step 26



Note T-Nut Orientation

Left Roof Panel

Roofing overhang

Front Post Assembly

Back Post Assembly


Underneath View

Hardware

2 x  (FW12 x 2, LN2)

26

Tighten all bolts





Hardware

2 x  (FW12 x 2, LN2)

27


Install screws Centered on Rafters



Hardware

8 x S11

Roof Panels removed for clarity



Hardware


16 x S12

Components


2 x Saddle Bracket (4pk)

29


DO NOT overtighten screws, could cause damage to roofing material




Align Holes



No screws



Tight



Roof Back Edge

Hardware



34 x R0

Components

2 x Roof Back Edge

30

DO NOT overtighten screws, could cause damage to roofing material




Align Holes

Roof Back Edge



Flat Roof Clip





Hardware

2 x R0

Components


1 x Roof Edge Centre



Components

1 x Flat Roof Cap - Short Top

1 x Flat Roof Cap - Bottom




Hardware

2 x 

33

DO NOT overtighten screws, could cause damage to roofing material




Hardware

34 x R0

Components

2 x Roof Back Edge

DO NOT overtighten screws, could cause damage to roofing material




Hardware

2 x R0

Components

1 x Roof Edge Centre

**Hardware**2 x 


Evenly distributed bead of sealant between the Center Cap and the Roof Edge Center



Note: All surfaces to be clean, dry, dust and grease free before application with temperatures above 5°C (41°F), no warmer than 35°C (95°F).



- Apply sealant in small beads and smooth as required.
- Clean excess with a cloth or paper towel before it skins over.
- Always wear safety glasses and rubber gloves when using product.

See page 6 for Warning and First Aid Information.



37

Attach Gazebo ID Plaque to a prominent location on your gazebo with two S12. This provides warnings concerning safety and important contact information.



Hardware

2 x S12

Components

1 x Gazebo ID Plaque

[illegible]



Customer Registration Card - Carte d'inscription du client - Tarjeta de Registro del Cliente

First Name - Prénom - Primer Nombre	Initial - Initiale - Inicial	Last Name - Nom de famille - Apellido

Street - Rue - Calle	PO Box - Boîte postale - Casilla postal	Apt. No. - App.

City - Ville - Ciudad	State/Province - État/Province - Estado/Provincia

ZIP/Postal Code - ZIP/Code postal - Código Postal	Country - Pays - País

E-mail Address - Adresse courriel - Dirección de E-mail	Telephone Number - N° de téléphone - No. de Teléfono

Model Name - Nom du modèle - Nombre del Modelo	Model Number (from front cover) - N° du modèle (page de couverture) - Número de Modelo (de la portada)

Date of Purchase - Date d'achat - Fecha de Compra (mm/dd/yyyy) (mm/jj/aaaa) (mm/dd/aaaa)	Place of Purchase - Lieu d'achat - Comprado a

Comments - Commentaires - Comentarios :

Mail To - Envoyer par courrier à - Enviar por Correo a:

Yardistry
375 Sligo Road West, PO Box 10
Mount Forest, Ontario, Canada, N0G 2L0
Attention: Consumer Relations
À l'attention de : Service à la clientèle
Atención a: Servicio de Atención al Cliente

Online Registration - Enregistrement en ligne - Registro online:

www.yardistrystructures.com/warranty

1.888.509.4382

Hours/ Heures/ Horas: 8:30 am - 5:00 pm EST
(excl. holidays/ hors jours fériés/ excepto los días festivos)

English and French Spoken / Anglais et français parlés / Inglés y francés hablado

Yardistry would like to say "Thank you" for your time and feedback.
Yardistry aimerait vous remercier d'avoir pris le temps de répondre au sondage.
Yardistry quiere "Agradecerle" por su tiempo y su opinión.